
RB-C004 User Manual



1. Connector Models

No.	Connector Model	No.	Connector Model
①	XT30 Port	⑪	EtherCAT Port
②	DisplayPort Interface	⑫	PoE Port (1×4-pin)
③	Dual USB3.1 Ports	⑬	PoE Port (1×4-pin)
④	Dual USB3.1 Ports		
⑤	RJ45 Ethernet Port		
⑥	USB Type-C Port		
⑦	EtherCAT Port		
⑧	EtherCAT Port		
⑨	EtherCAT Port		
⑩	EtherCAT Port		

2. RB-C004 Flashing Guide

Access URL: https://myactuatornextcloud.hsk.top/s/DBtDJddenY4zyxE

3. Raybot Studio and Document Access

1. Shortcuts for Raybot Studio motor management software and related documents are placed on the desktop.
2. Raybot Studio is accessible within the same local - area network: Run `ifconfig` on the controller to get the device IP address. Enter `Device-IP:5173` (example: `192.168.1.100:5173`) in the browser of another device to visit Raybot Studio.